

2026-03-23
54x22cm

单层

正面

标注：森迈二代单交叉聚拢200L，200g铜版纸，彩色印刷

反面

A181-001-001



PRODUCT MATERIAL:
Plastic, Metal, Nylon

PRODUCT SIZE:965x600x1070mm(unfold wagon)
350x250x650mm(folded wagon)
955x603x10mm(tabletop)
2885x2550mm(canopy)

QTY:
Folding wagon x1,Tabletop x1,Canopy x1

WEIGHT:
G.W.-16.7KG,N.W.-15.8KG
Max Static Load: 150 KG (When stationary)
Max Dynamic Load: 80-90KG (When moving)
maximum load-bearing capacity of tabletop is 20KG



Scan the QR code for assembly videos

Email: patio@homeselecting.com

WARNING

For your safety and to avoid any damage or inconvenience, please carefully review the following instructions before using this product.

.This product is designed exclusively for adult use. It is not suitable for elderly individuals with restricted mobility to operate or utilize. Additionally, please ensure that children do not ride inside the wagon.

.When this product is in use, children must always be under the supervision of an adult.

.To ensure the safety and longevity of your product, please avoid overloading, improper folding, or using non-approved parts, Carefully review the provided instructions to ensure proper usage.

.When adjusting any movable accessories on this product, please maintain a safe distance from moving parts to prevent injury.

. For your safety, please avoid using this product in areas with uneven surfaces.

.During use, please ensure this product is kept away from fire, high temperatures, pools, power sources, and maintain a safe distance at all times.

.This product is designed with a recommended weight capacity of 100KG and is important to distribute items placed within the wagon evenly to ensure optimal balance and stability.

.Avoid placing this product on roads, ramps, or in hazardous areas to ensure safety.

.Exercise caution to prevent fingertip pinching when folding and unfolding this product.

.Before placing items, please ensure that the wagon is fully opened. If you detect any damage to this product, cease usage immediately and reach out to customer service for further assistance.

.This product is designed for use only at walking speed. .This wagon is designed for carrying objects. For personal safety, it is not recommended for adults or children to use it as a ride, as doing so may lead to bumps, scratches, or other accidents.

Not suitable for children to ride
This is NOT a toy

Avoid Pinch Injury, keep fingers clear of hinged joints when folding and unfolding the wagon

Maintenance

1. When cleaning the fabric, hand wash it with water below 30°C and do not bleach.
2. When cleaning the frame, use a soft, dry cloth to wipe it.
3. Regularly inspect your wagon and promptly replace or repair any loose or worn parts, fallen materials, or gaps in seams.
4. Please avoid excessive exposure of this product to the sun to prevent the vehicle from aging or deforming.
5. In the event of rain or moisture, unfold the wagon to allow any water to drain, and fold it up once it's dry.

Warranty

For a period of one (1) year after date of purchase, the Manufacturer will either repair or replace defective components in accordance with this Limited Warranty. This warranty is between the Manufacturer and the original purchaser and is valid only when accompanied by the original purchaser's sales receipt showing original date of purchase.

The manufacturer or its authorized dealer can accept or reject warranty claims based on its findings. This warranty applies in normal residential use only and is not intended for commercial use. The Manufacturer can make substitutions as required of materials, components, and sub-components of comparable value and utility. This warranty is limited to product repair or replacement (to be determined solely by the Manufacturer). Warranty return is limited to only the single affected component.



This limited warranty covers only manufacturing defects and does not cover normal wear and tear, damage due to acts of nature (such as, but not limited to freezing or high winds), abuse or misuse, including chemical damage from sun tan oil or other chemicals, exposure to extreme heat or cold, abrasion or excessive weight. This product is intended to be used in standard installations only. This warranty is void if the product is not used for its intended purpose. The Manufacturer disclaims liability for any aspect of installation and any inconvenience caused by a defective part of a component

Certain items are not covered by this warranty. These include, but are not limited to the following:



1. Components subjected to abuse, including abuse intended to simulate failure
2. Damages caused by retailer, shipper or installation error (such as scratches, dents, tears, chips, etc.)
3. Any part that only shows normal wear and tear on the surface, including debris, scratches, or material stretching and stitching.
4. Tears, punctures, scratches or any damage caused by improper installation or use.

*** If you need after-sales service, please provide the original purchase record and a brief description of the problem. Please also provide your email address or mobile number**

Step 1:
Expand the camping wagon.




Step 2:
Secure the tabletop onto the frame.



HOW TO SETUP CANOPY

Step 3:
Install vertical bar & X cross bar




Insert and snap

Insert and lock


Insert, twist and lock

Install the top aluminum pole frame



Insert, twist and lock

Step 4:
Laying canopy fabric



Aluminum bar head featuring embedded webbing holes. Pull the webbing with one hand while holding the aluminum pole with the other.

Note: To ensure your safety and enhance your user experience, please utilize stakes for reinforcement in case of changing weather conditions.

Note:

1. It is not recommended to use this product in bad weather such as strong winds and heavy rains
2. Avoid proximity to open flames, sharp objects, hazardous power sources, and bodies of water, maintaining a safe distance at all times.
3. Please check the weather forecast before using this product. If wind speeds reach level 4 or higher, we recommend securing it with stakes for added stability.
4. When you notice any damage to this product, cease use immediately and contact our customer service team for assistance.
5. This product is intended for operation by adults only. Children and elderly individuals with limited mobility are not permitted to install or use it.
6. We advise against using this product on uneven roads.

18cm

18cm

18cm